



# VistaEY2H\_Demo

This package contains the demonstration software for the Vista Imaging VistaEY2H Biometric camera.

This software will work on the 32 and 64 bit versions of Windows XP, Windows Vista, Windows 7, and Windows 8.

The VistaEY2H\_Demo package contains the following folders:

- Exe - Executable VcViewEY2H application and API Library DLL.
- Firmware - Current Firmware File and Update Utility
- Install - Driver installation files.
- Readme.pdf - This file.

## **Installation Procedure:**

From the Install folder, run the VcInstallEY2H utility to Install and Uninstall the VistaEY2H drivers.

- On Windows XP, the user needs to be logged in with Administrator privileges.
- On Windows Vista, Windows 7, and Windows 8, the VcInstallEY2H program will ask for elevated privileges.

## **Run the Demo**

Plug the camera in and wait a few seconds for device enumeration to complete.

From the Exe folder, run the VcViewEY2H.exe application.

## **Firmware Update**

Start the VcViewEY2H application and select the Help\About menu to display the current camera version information. Verify that the camera firmware version matches the version in the Firmware folder. If not, refer to the VII FW Update Procedure document in the Firmware folder for firmware update instructions.